



G-Kii

To really hit the spot...



5 speeds 7 patterns



Quiet



Bodysafe



Waterproof




Rechargeable

1 year warranty.

Simultaneous G-spot and clitoral stimulation, the design-led and distinctive G-Kii can be curved into the perfect position at the touch of a button to suit your body shape and pleasure preference.

Deeper richer sensations

G-Kii's motor is designed to a low frequency to give our signature Je Joue oh-so-low rumbling vibrations. With 5 speeds and 7 patterns, G-Kii offers a wide range of vibrations – from a gentle purr to a deep rumble.



Creative Tips

G-beginner: Studies say that a majority of women are more likely to experience a clitoral orgasm than a vaginal one ... Sounds familiar? If so, we recommend you start using G-Kii completely curved to stimulate both the clitoris and G-spot area. Use an up and down rocking motion, close your eyes, relax and you'll soon realise that your G-spot does exist! As you get more comfortable, you won't need as much clitoral stimulation and will want to focus more on the G-spot. Rocking G-Kii up and down will allow you to alternately hit either the clitoris or the G-spot and help you differentiate where your pleasure comes from.

Once you're familiar with your inner sensation use G-Kii in its extended position to start building up your G-orgasm.

This open angle is probably the best for games with your partner, allowing him or her to pilot your G-experience.

G-expert: If you're a G-expert, reverse the process; start with step 3 and finish with step 1. There are no rules, so feel free to shuffle around all the angles of G-Kii.

JE JOUE

How it works

Discreet, comfortable and safe

- To start the toy, hold + for 2 seconds to turn G-Kii on
- To increase vibration, click +
- To change from a constant vibration to a pulse vibration, click the ~ (middle button). To decrease vibration click -
- To turn G-Kii off, hold - for 2 seconds
- To adjust the angle of your G-Kii, press the button on the side of the toy. You may have to wiggle the head to aid movement

How it charges

Quick and easy

To charge your G-kii, please place the charger directly over the G-Kii's buttons and you'll feel the magnets pull it into place (G-Kii charges through its buttons). When charging, the light will flash. When fully charged the light will stay on, until the charger is removed from the buttons. 2 hours of charge gives you 2 hours of play.

How to clean

We recommend using only water-based lubricants with G-Kii. We recommend washing G-Kii in warm water and soap or a toy cleaner.

Additional Facts

The G-spot does exist! And these sex toys can help you to find it. The G-spot is an area of highly sensitive nerve endings inside the body that can, when stimulated properly, lead to incredible orgasms for both men and women. In women, the G-spot is typically located about two inches inside the vagina towards the belly button, and is roughly walnut-sized.

JE JOUE

Barcodes (EANs)



G-Kii Black
5060170970553



G-Kii Purple
5060170970577



G-Kii Fuchsia
5060170970584

Toy Specs

Height 172/132.5/109.3 mm
Width 51 mm
Depth 63.1/80.1/113 mm
Total Weight 192.2 g



Case Specs (USB)

G-Kii	Number of units	Total Weight (kg)	Height (mm)	Width (mm)	Depth (mm)
Single box	1	0.65	80	309	78
Half case	8	5.71	345	340	180
Case	16	12.20	370	380	370