

DEEP SENSE®


SENSE TOUCH MASTUBATOR REUSABLE- ♂

11 VIBRATIONS • 7 INTENSITIES



RECHARGEABLE

SENSE TOUCH




DEEP SENSE®

SENSE TOUCH MASTUBATOR REUSABLE- ♂

11 VIBRATIONS • 7 INTENSITIES

RECHARGEABLE



HOW TO USE

- Press button On/off For 3 sec to turn On/off.
- Vibration up and down by pression the button + and - .
- On stand by status, press On/off for 2 sec for SENSE TOUCH and the LED : light flash.
- Press On/off for 2 sec to come to stand by status.
- Press On/off for 3 sec to turn off.



1.Open the cover



2.Unscrew the ring



3.Taking out the inner part




4.Openning the inner part and clean them

DEEP SENSE®

SENSE TOUCH MASTUBATOR REUSABLE- ♂

11 VIBRATIONS • 7 INTENSITIES

RECHARGEABLE



Compatible with
QUICK WARM®



BENEFICES

- 11 vibration modes with "SENSE TOUCH" mode
- 7 intensities
- 2 ultra strong motors
- TPE sleeve with pins and grooves
- Reusable sleeve, easy to clean
- Compatible with Quick warm (#6072134)
- Ultra-realistic sensations
- USB rechargeable
- Ultra-Soft Silicone + ABS
- Running time: 1h30
- Charging time : 2h
- Phthalate-free soft silicone
- Dimensions : 22 cm x 9 cm / 8,66" X 3,54"

PLUS PRODUIT

- Pouch included
- USB rechargeable (included)

REF : 6072127

- EAN 3700436072127
- Packaging : carton box
- Weight : net 383 gr / gross : 551 gr
- Packing : master 24 pcs + inner 6 pcs
- **WS: 108,33 €**
- MSRP: 129,99€

